

# ACP-IMX6POS-B1

NXP i.MX6 Cortex-A9 SBC (B Version)

## User's manual

---

1<sup>st</sup> Ed – 11 November 2019

## **FCC Statement**



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

## **Notice**

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

## **Copyright Notice**

Copyright © 2019 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

## **Trademark Acknowledgement**

Brand and product names are trademarks or registered trademarks of their respective owners.

## **Disclaimer**

Avalue Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Avalue Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless

2 ACP-IMX6POS-B1 User's Manual

## **ACP-IMX6POS-B1 User's Manual**

otherwise specified. Applications that are described in this manual are for illustration purposes only. Avalue Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

### **Life Support Policy**

Avalue Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE PRIOR WRITTEN APPROVAL OF Avalue Technology Inc.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

### **A Message to the Customer**

#### ***Avalue Customer Services***

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

#### ***Technical Support***

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalue.com.tw/>

### *Product Warranty*

Avalue warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Avalue, or which have been subject to misuse, abuse, accident or improper installation. Avalue assumes no liability under the terms of this warranty as a consequence of such events. Because of Avalue's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If any of Avalue's products is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details. If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU type and speed, Avalue's products model name, hardware & BIOS revision number, other hardware and software used, etc.) Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your good return more quickly.
4. Carefully pack the defective product, a complete Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

# CONTENT

<b>1. Getting Started</b>	<b>7</b>
1.1 Safety Precautions	7
1.2 Packing List	7
1.3 Document Amendment History	8
1.4 Manual Objectives	9
1.5 System Specifications	10
1.6 Architecture Overview – Block Diagram	12
<b>2. Hardware Configuration</b>	<b>13</b>
2.1 Product Overview	14
2.2 Jumper and Connector List	15
2.3 Setting Jumpers & Connectors	17
2.3.1 Boot mode selector (JBTSL1)	17
2.3.2 Serial port 1/2 pin9 signal select (JCOM12-RI)	18
2.3.3 Serial port 3/4 pin9 signal select (JCOM34-RI)	18
2.3.4 Serial port connector 3/4 (JCOM3/4)	19
2.3.5 USB connector 1 (JUSB1)	19
2.3.6 USB connector 2 (JUSB2)	20
2.3.7 LED connector (JLED1)	20
2.3.8 General purpose I/O connector (JDIO)	21
2.3.9 Power connector (JPWR2)	21
2.3.10 Speaker Out_L connector (JSPK1)	22
2.3.11 Speaker Out_R connector (JSPK2)	22
2.3.12 Line In, MIC connector (JMIC1)	23
2.3.13 LCD inverter connector (JBKLT1)	23
2.3.14 VGA connector (JVGA1)	24
2.3.15 Battery holder (BAT-1)	24
2.3.16 LVDS connector (JLVDS1)	25
2.3.17 I2C device connector (JI2C1)	26
<b>3. Software User Guide</b>	<b>27</b>
3.1 Build and install U-boot & Kernel image for ACP-IMX6POS	28
3.1.1 Requirements	28
3.1.2 Setting Up the Standalone Cross-Development Environment	28
3.2 Get U-boot & Kernel source code and Compiler	28
3.2.1 Get U-boot & Kernel source code	28
3.2.2 Compiler U-boot & Kernel image	29

## ACP-IMX6POS-B1 User's Manual

3.3	Flash U-boot & Kernel image to eMMC or MicroSD .....	30
3.3.1	Flash U-boot & Kernel image to eMMC.....	30
3.3.2	Get MFG tool.....	32
3.3.3	Flash OS to eMMC by MFG tool .....	32
3.3.4	Flash OS to SD card by MFG tool.....	34

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

## 1.2 Packing List

Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 x ACP-IMX6POS-B1 Module

### 1.3 Document Amendment History

Revision	Date	Comment
1 <sup>st</sup>	November 2019	Initial Release



### 1.4 Manual Objectives

This manual describes in detail the Avalue Technology ACP-IMX6POS-B1 Single Board.

We have tried to include as much information as possible but we have not duplicated information that is provided in the standard IBM Technical References, unless it proved to be necessary to aid in the understanding of this board.

We strongly recommend that you study this manual carefully before attempting to interface with ACP-IMX6POS-B1 series or change the standard configurations. Whilst all the necessary information is available in this manual we would recommend that unless you are confident, you contact your supplier for guidance.

Please be aware that it is possible to create configurations within the CMOS RAM that make booting impossible. If this should happen, clear the CMOS settings, (see the description of the Jumper Settings for details).

If you have any suggestions or find any errors concerning this manual and want to inform us of these, please contact our Customer Service department with the relevant details.

## 1.5 System Specifications

<b>System</b>	
<b>Mother Board</b>	ACP-IMX6POS(B)
<b>CPU</b>	NXP i.MX6 Cortex-A9 Quad / Dual Lite 1GHz
<b>CPU Cooler (Type)</b>	Aluminum CPU Sink E1961213015000R, Heatsink for CPU 41*41*20mm
<b>Memory</b>	2GB DDR3L
<b>Storage</b>	8G eMMC
<b>Power Supply</b>	DC in 12V~24V
<b>Display</b>	
<b>Chipset</b>	NXP i.MX6
<b>Resolution</b>	Up to 1920x1080
<b>Multiple Display</b>	Quad(VGA+HDMI or LVDS+HDMI or VGA+LVDS) Dual Lite(LVDS+HDMI)
<b>HDMI</b>	From NXP i.MX6
<b>LCD Interface</b>	Dual channel 24bit LVDS
<b>Ethernet</b>	
<b>LAN1</b>	Giga Lan From i.MX6 MAC, PHY is Micrel KSZ9031RNX
<b>LAN2</b>	Giga Lan Intel I210 by PCIe Interface
<b>Ethernet Interface</b>	RJ45 x2
<b>Audio</b>	
<b>I2S Codec</b>	Wolfson WM8962
<b>Audio Port</b>	2Pin Wafer Box P=2.0m x2 (Speaker out R & L ) (Driver per channel max 2W)
<b>Mic</b>	4Pin Wafer Box P=2.0m x1(Microphone)
<b>Internal I/O Connectors</b>	
<b>Front panel</b>	JLED1 2 x 5P x1
<b>mini-PCIe socket</b>	MPCIE1 x1
<b>SIM socket</b>	SIM1 x1
<b>OTG jumper</b>	JBTSL1 x1
<b>I2C</b>	JI2C1 x1
<b>MIC</b>	JMIC1 x1
<b>LVDS</b>	JLVDS1 x1
<b>Black Light</b>	JBKLT1 x1
<b>VGA</b>	JVGA1 x1
<b>USB</b>	JUSB2 x1

## ACP-IMX6POS-B1 User's Manual


	JUSB1 x1
<b>Mic or SD socket</b>	JMSD x1
<b>GPIO</b>	JDIO 16bit x1
<b>power input</b>	JPWR2 Pin header 4P power input connector
<b>Speaker</b>	JSPK1 x1 JSPK2 x1
<b>RS232</b>	JCOM 3&4 x1 as pin header only RS232.
<b>Debug</b>	JUART1 x1
<b>External I/O</b>	
<b>USB</b>	USB Type A Double Deck x 1
<b>LAN</b>	RJ45 connector with indicate LED x 2
<b>HDMI</b>	HDMI connector x 1 (Vertical type)
<b>Mini-USB</b>	Mini-USB connector x 1
<b>COM Port</b>	DB9 male connector x2 JCOM1&2 can be select from RS232/422/485 (RS485 auto flow control)
<b>DC Jack</b>	JPWR1 x1
<b>Mechanical &amp; Environmental</b>	
<b>Power Type</b>	12V ~ 24V wide voltage DC input
<b>Power Connector Type</b>	1. DC jack 2. Pin header 4P power input connector
<b>Weight</b>	TBD
<b>Fanless</b>	Yes
<b>Size (L x W)</b>	175 x 110mm
<b>OS Support</b> (listed in accordance with Intel document)	Android 4.4.2 Linux Ubuntu 14.04 Linux Yocto 1.5.1



**Note:** Specifications are subject to change without notice.

## 1.6 Architecture Overview – Block Diagram


The following block diagram shows the architecture and main components of ACP-IMX6POS-B1.



# 2. Hardware Configuration

---


## 2.1 Product Overview



## 2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board's jumpers and connectors.

### Jumpers

Label	Function	Note
JBTSL1	Boot Mode selector	Switch, 2bit
JCOM12-RI	Serial port 1/2 pin9 signal select	6 x 2 header, pitch 2.00mm
JCOM34-RI	Serial port 3/4 pin9 signal select	6 x 2 header, pitch 2.00mm

### Connectors

Label	Function	Note
BAT-1	Battery holder	1 x 2 wafer, pitch 1.25mm
JCOM1/2	Serial port connector 1/2	D-sub 9-pin, male
JCOM3/4	Serial port connector 3/4	5 x 2 wafer, pitch 2.00 mm
JDIO	General purpose I/O connector	10 x 2 header, pitch 2.00 mm
JUSB1	USB connector 1	5 x 2 wafer, pitch 2.00mm


**ACP-IMX6POS-B1 User's Manual**




<b>JUSB2</b>	USB connector 2	5 x 1 wafer, pitch 2.00mm
<b>JUSB3</b>	USB connector 3	USB Type-A x2
<b>JMUSB1</b>	Mini USB connector for Boot/Debug	MINI USB-MAB_5P
<b>JPWR1</b>	DC-IN power connector	Power Jack mini din 4P
<b>JPWR2</b>	Power connector	2 x 2 wafer, pitch 4.20 mm
<b>MPCIE1</b>	Mini PCI Express connector	
<b>JLAN1/2</b>	RJ-45 Ethernet connector 1/2	
<b>JVGA1</b>	VGA connector	8 x 2 wafer, pitch 2.00mm
<b>JLED1</b>	LED connector	5 x 2 wafer, pitch 2.00mm
<b>JSPK1</b>	Speaker Out_L connector	2 x 1 wafer, pitch 2.00 mm
<b>JSPK2</b>	Speaker Out_R connector	2 x 1 wafer, pitch 2.00 mm
<b>JLVDS1</b>	LVDS connector	2 x 20 wafer, pitch 1.25 mm
<b>SIM1</b>	SIM Card Slot	SDCARD_9H
<b>JMIC1</b>	Line In, MIC connector	4 x 1 wafer, pitch 2.00mm
<b>JBKLT1</b>	LCD inverter connector	5 x 1 wafer, pitch 2.00mm
<b>JMSD1</b>	Micro SD Card Slot	
<b>JHDMI1</b>	HDMI connector	
<b>JI2C1</b>	I2C device connector	5 x 1 header, pitch 2.00mm





## 2.3 Setting Jumpers & Connectors

### 2.3.1 Boot mode selector (JBTSL1)





Mode	Description
	OTG load
	eMMC boot
	SD boot

2.3.2 Serial port 1/2 pin9 signal select (JCOM12-RI)





\* Default

2.3.3 Serial port 3/4 pin9 signal select (JCOM34-RI)





\* Default

2.3.4 Serial port connector 3/4 (JCOM3/4)





Signal	PIN	PIN	Signal
NC	1	2	COM_RXD
COM_TXD	3	4	NC
GND	5	6	NC
COM_RTS#	7	8	COM_CTS#
COM_RI_A	9	10	GND

2.3.5 USB connector 1 (JUSB1)





Signal	PIN	PIN	Signal
+5V	1	2	+5V
USB_NP2	3	4	USB_NP1
USB_PP2	5	6	USB_PP1
GND	7	8	GND
GND	9	10	GND

2.3.6 USB connector 2 (JUSB2)




Signal	PIN
+5V	1
USB_NP3	2
USB_PP3	3
GND	4
GND	5

2.3.7 LED connector (JLED1)





Signal	PIN
PWR-LED+	1
PWR-LED-	2
WIFI-LED+	3
WIFI-LED-	4
LAN-LED+	5
LAN-LED-	6
Reset Switch	7
	8
Power button Switch	9
	10

2.3.8 General purpose I/O connector (JDIO)




Signal	PIN	PIN	Signal
DI0	1	2	DO0
DI1	3	4	DO1
DI2	5	6	DO2
DI3	7	8	DO3
DI4	9	10	DO4
DI5	11	12	DO5
DI6	13	14	DO6
DI7	15	16	DO7
GPIO_05_I2C3_CLK	17	18	GPIO_06_I2C3_SDA
GND	19	20	+VCC_DIO

2.3.9 Power connector (JPWR2)




Signal	PIN	PIN	Signal
GND	2	4	+VDC_IN
GND	1	3	+VDC_IN

2.3.10 Speaker Out\_L connector (JSPK1)




Signal	PIN
SPKL_N	1
SPKL_P	2

2.3.11 Speaker Out\_R connector (JSPK2)





Signal	PIN
SPKR_N	1
SPKR_P	2

2.3.12 Line In, MIC connector (JM1C1)





Signal	PIN
MIC_DET	1
MIC_IN	2
MICBIAS	3
GND	4

2.3.13 LCD inverter connector (JBKLT1)




Signal	PIN
+12V	1
GND	2
LVDS_BPEN	3
LVDS_BKLCTL_R	4
+5V	5

2.3.14 VGA connector (JVGA1)



Signal	PIN	PIN	Signal
+5V	1	2	VRED
GND	3	4	VGREEN
NC	5	6	VBLUE
VDATA	7	8	NC
VHS	9	10	GND
VVS	11	12	GND
VCLK	13	14	GND
GND	15	16	GND


2.3.15 Battery holder (BAT-1)



Signal	PIN
+V_BAT	1
GND	2





2.3.16 LVDS connector (JLVDS1)



Signal	PIN	PIN	Signal
+12V	39	40	+12V
GND	37	38	GND
LVDS1_CLK_N	35	36	LVDS0_CLK_N
LVDS1_CLK_P	33	34	LVDS0_CLK_P
GND	31	32	GND
LVDS1_TX3_N	29	30	LVDS1_TX2_N
LVDS1_TX3_P	27	28	LVDS1_TX2_P
GND	25	26	GND
LVDS1_TX1_N	23	24	LVDS1_TX0_N
LVDS1_TX1_P	21	22	LVDS1_TX0_P
GND	19	20	GND
LVDS0_TX3_N	17	18	LVDS0_TX2_N
LVDS0_TX3_P	15	16	LVDS0_TX2_P
GND	13	14	GND
LVDS0_TX1_N	11	12	LVDS0_TX0_N
LVDS0_TX1_P	9	10	LVDS0_TX0_P
GND	7	8	GND
LVDS2_DDC_CLK	5	6	LVDS2_DDC_DATA
+3V	3	4	+5V
+3V	1	2	+5V

2.3.17 I2C device connector (J12C1)



Signal	PIN
CS_+V3.3S	1
CS_INT#	2
CS_CLK	3
CS_DAT	4
GND	5

# 3. Software User Guide

---

### 3.1 Build and install U-boot & Kernel image for ACP-IMX6POS

#### 3.1.1 Requirements

Requirements for the set up of the standalone cross-development environment:

- x86 host system (64-bit)
- recommended free disk space: 25 GB
- recommended memory size: 8 GB
- Ubuntu 14.04 (64-bit)

#### 3.1.2 Setting Up the Standalone Cross-Development Environment

Here you can find instruction to setup development environment for Android source code for ACP-IMX6POS and the way to install it on eMMC. With this guideline, user will be able to setup the system easily and test all the functions with the system.

3.1.2.1 Perform a standard Ubuntu 14.04 (64-bit) installation.

3.1.2.2 Install additional packages:

```
$ sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib \
build-essential chrpath socat libstd1.2-dev
```

```
$ sudo apt-get install libstd1.2-dev xterm sed cvs subversion coreutils texi2html \
docbook-utils python-pysqlite2 help2man make gcc g++ desktop-file-utils \
libgl1-mesa-dev libglu1-mesa-dev mercurial autoconf automake groff curl lzop asciidoc
```

```
$ sudo apt-get install u-boot-tools
```

### 3.2 Get U-boot & Kernel source code and Compiler

#### 3.2.1 Get U-boot & Kernel source code

Please connect Avalue FAE to get source code.

# ACP-IMX6POS-B1 User's Manual

## 3.2.2 Compiler U-boot & Kernel image.

Please unzip the source code in your computer and enter to U-boot & Kernel source code folder.

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel$ ls  
fsl kernel u-boot
```

Enter to “u-boot“ folder and type “./run.sh -j4” start to compiler u-boot.

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/u-boot$ ls  
api common disk examples lib MAKEALL net scripts  
arch config.mk doc fs lib_arm Makefile post snapshot.commit  
board cpu drivers include lib_generic mkconfig README test  
boards.cfg CREDITS dts Kbuild Licenses nand spl run.sh tools
```

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/u-boot$ ./run.sh -j4
```

After compiler finish, there is the “out” folder would be created in u-boot source code folder.

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/u-boot$ ls  
api common disk examples lib MAKEALL net run.sh tools  
arch config.mk doc fs lib_arm Makefile out scripts  
board cpu drivers include lib_generic mkconfig post snapshot.commit  
boards.cfg CREDITS dts Kbuild Licenses nand spl README test
```

You can find the u-boot image in out folder.

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/u-boot/out$ ls  
arch disk fs Makefile source tools u-boot_e9697imx60br_emmc.imx u-boot.map  
board drivers include net System.map u-boot u-boot.imx u-boot.srec  
common examples lib scripts test u-boot.bin u-boot.lds
```

Enter to “kernel” folder and type “./run.sh -j4” start to compiler kernel.

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/kernel$ ls  
arch CREDITS drivers include Kbuild lib mm REPORTING-BUGS scripts tools  
block crypto firmware init Kconfig MAINTAINERS net run.sh security usr  
COPYING Documentation fs ipc kernel Makefile README samples sound virt
```

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/kernel$ ./run.sh -j4
```

After compiler finish, there is the “out” folder would be created in Kernel source code folder.

```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/kernel$ ls  
arch Documentation init lib out scripts virt  
block drivers ipc MAINTAINERS README security  
COPYING firmware Kbuild Makefile REPORTING-BUGS sound  
CREDITS fs Kconfig mm run.sh tools  
crypto include kernel net samples usr
```


You can find the kernel image in out folder.




```
jerry@AE-RISC:~/project/Jerry/IMX6/FSL-Kernel/kernel/out$ ls  
arch e9697imx6e2r.dtb init modules net usr  
block e9697imx6e3r.dtb ipc modules.builtin scripts vmlinux  
crypto firmware kernel modules.order security vmlinux.o  
drivers fs lib Module.symvers sound zImage_e9697imx60br  
e9697imx60br.dtb headers Makefile mx6dlpos.dtb source  
e9697imx6e1r.dtb include mm mx6gpos.dtb System.map
```

### 3.3 Flash U-boot & Kernel image to eMMC or MicroSD

#### 3.3.1 Flash U-boot & Kernel image to eMMC


##### 3.3.1.1 Set the jumper to OTG mode



Mode	Description
 21 on	OTG load
 21 on	eMMC boot
 21 on	SD boot

# ACP-IMX6POS-B1 User's Manual

## 3.3.1.2 Connect ACP-IMX6POS-B1 to computer through JMUSB1 by mini USB.



# ACP-IMX6POS-B1 User's Manual


## 3.3.2 Get MFG tool

Please connect Avalue FAE to get MFG tool.


## 3.3.3 Flash OS to eMMC by MFG tool

### 3.3.3.1 Execute vbs file


Please enter to MFG-Tools\vbs and execute xxxxxxxxxxx-3.14.28\_1.0.0-emmc.vbs.



After execute xxx-emmc.vbs, please press “Start” to start flash OS.



After flash finish, please press “Stop”.









# ACP-IMX6POS-B1 User's Manual

## 3.3.3.2 Boot to OS from eMMC


Set the jumper to “eMMC boot” and power on to boot to OS.




Mode	Description
 <p>21 on</p>	OTG load
 <p>21 on</p>	eMMC boot
 <p>21 on</p>	SD boot

### 3.3.4 Flash OS to SD card by MFG tool


3.3.4.1 Please enter to MFG-Tools\vbs and execute xxxxxxxxxxx-4.1.15\_1.0.0-sd.vbs.



After execute xxx-emmc.vbs, please press “Start” to start flash OS.




After flash finish, please press “Stop”.






# ACP-IMX6POS-B1 User's Manual

## 3.3.4.2 Boot to OS from SD card

Set the jumper to “SD boot” and power on to boot to OS.



Mode	Description
 on	OTG load
 on	eMMC boot
 on	SD boot

